

MAKE SURE TEMPLATE PRINTED AT 100% SCALE AND MATCHING MEASUREMENTS



IM SKIVING UPPER TIPS OF BOTTOM POCKET AND BOTTOM TIPS OF UPPER POCKET (DASHED LINE) UNDER 30-45 DEGREES ANGLE TO JOIN THEM ONE ON TOP OF OTHER



**WATCH MY SHORT YOUTUBE VIDEO TO UNDERSTAND WHAT I MEAN AT MY YOUTUBE CHANNEL "STR HANDMADE"
[HTTPS://YOUTU.BE/BFEWW4_KI04](https://youtu.be/BFEWW4_KI04)**



SCAN FOR QUICK VIDEO ACCESS

IF YOU ARE GOING TO USE THIS TECHNIQUE THEN CUT UPPER POCKET BY FOLLOWING DASHED LINE (+2MM) IF YOU ARE GOING TO JOIN POCKETS SIMPLE WAY, JUST CUT BY REGULAR LINE AND IGNORE DASHED LINE.