

# Instruction

Step 1: Fold pen slot and glue, make sure stitching holes are aligned with each other, sew along stitching to form the pen slot. Then shoot snap on.



