

ACC-155 Front stiffener A x1  
B01

Note: 0.5mm (1.25oz) leather is advised.


Thin shadow area


www.leathercraftpattern.com


ACC-155 Front stiffener B x1  
B02

Note: 0.4mm TYLIN spunlace is advised.

www.leathercraftpattern.com









ACC-155 Front pocket lining x1  
A04

Note: 0.5mm (1.25oz) leather is advised.

www.leathercraftpattern.com








www.leathercraftpattern.com


ACC-155 Back stiffener A x1  
B03


Note: 0.5mm (1.25oz) leather is advised.


Thin shadow area
















Note: 2.0mm vegetable tanned leather is  
applied, wrapped by a piece of 0.5mm leather.

ACC-155 Flap supporter x1  
A08

3.0mm

Thin shadow area  
and fold edge.

Zipper orienting line  
189mm No.3 zipper


Zipper orienting line  
189mm No.3 zipper

3.0mm

A10 Orienting line

ACC-155 Back pocket surface x1  
A08

Note: 0.5mm (1.25oz) leather is advised.





ACC-155 Back pocket lining x1  
A09

Note: 0.5mm (1.25oz) leather is advised.



ACC-155 Zipper cover x1  
A10

Note: 0.5mm (1.25oz) leather is advised.

ACC-155 Flap x3  
A11

Note: 1.0mm (2.5oz) leather is advised.

3.0mm

3.0mm

3.0mm

**Note: 1.0mm (2.5oz) leather is advised.**



1 tooth


3.0mm

3.0mm

1 tooth

3.0mm







ACC-155 Bottom stitffener x2

B05


Note: 2.0mm vegetable tanned leather is advised.


www.leathercraftpattern.com











ACC-155 Gusset binder x4  
A20

Note: 0.5mm (1.25oz) leather is advised,  
it is designed longer than real need.

Joint line h

Joint line i

ACC-155 Bottom binder x1  
A21

Note: 0.5mm (1.25oz) leather is advised,  
it is designed longer than real need.

Joint line j