


Compact & Plump Wallet

This pattern is provided by
PLAN.B LEATHER

● GUIDE



RD : Diameter(mm) of Round

HD : Diameter(mm) of Hole Punch



Select before printing, "Actual Size" or
print scale 100% in the printer settings.

● MATERIAL USED

► LEATHER

Pueblo Leather (BADALASSI CARLO TANNERY, Italy)
Color : Olmo, Coccinella / Temper : Semi-Stiff

Thickness : COVER, BODY : (1.5mm / 3.75oz / 0.059 in)
CAP BACK, PARTITION : (1.0mm / 2.5oz / 0.039 in)

► THREAD

Vinyo MBT
Thickness no : #5
Color no : 144

► CHISEL

Spacing : 4mm
Type : diamond

★ Set the leather thickness and stitch spacing according to your preference.






► Making Video : <https://youtu.be/sIP1G5wZCpw>





► Youtube Channel : <https://youtube.com/@plan.b>

COVER

TEST SCALE RULER




BODY, PARTITION





POSITION OF STAMP

This pattern is provided by
PLAN.B LEATHER




TIP

This pattern is provided by
PLAN.B LEATHER




If reinforcement is needed when installing the button.
Attach reinforced leather.


When attaching leather, align the centers of the holes.




Skiving




Skiving the ends as thin as possible.



Hammer it to make the angle gentle.






It is difficult to do side punching after everything is combined.

Therefore, if you drill a hole in advance, it will be easier to punch it at the end.

It doesn't matter if you punch it after combining it all.



Thank You For Your Purchase!