

BIKER WALLET PATTERN

«BRUTAL PETE»



For this project, I recommend vegetable tanned leather with a thickness of 1.2 - 1.4 mm.

You will learn some information from the video tutorial <https://youtu.be/hdm5o5X0qF4>

The pattern cannot be transferred, sold, donated to third parties without the consent of the Author. The pattern is not intended for public placement on the Internet.

TEST PAGE

Make sure these dimensions are correct before
starting your pattern











