

# HIP POUCH PATTERN 1

Print at 100%,  
Two 8-1/2 x 11 Pages  
Line Up End to End in this Order  
for Pattern

1

2

May have white areas between pages just  
continue line work with pencil or pen,  
do not overlap

9-1/2" / 24.13 cm

5/8" /  
1.58 cm

3/4" /  
1.90 cm

5/8" /  
1.58 cm

1" /  
2.54 cm

1-1/2" / 3.81 cm

CUT 2  
1 UP / 1 DOWN

