


HIP POUCH PATTERN 4



Print at 100%,
Two 8-1/2 x 11 Pages
Line Up End to End in this Order
for Pattern

1	2
---	---

May have white areas between pages just
continue line work with pencil or pen,
do not overlap

