SEWING INSTRUCTION

Dress "Jasmin"
Model 120-20
Sizes 36-48





Due to an embroidery promotion, the embroidery design is available for free in June and July 2023 with the code **B2TT9GA4** via embroideryonline.com

PRINT THE CUT

1. Open the pattern PDF and set the control square to Page 1 with the setting "Original size" on DIN Print A4 paper (US-Letter) (do not click on "Adjustment to page size"!)
2. Check the square – if it is 10 x 10 cm, print out the whole cut sheet.
3. Place all pages next to each other as indicated by the arrows and adhere them row by row along the boundary lines, then glue the rows together.
4. Compare the body measurements with the table measurements and cut out the cut parts in the appropriate size (the overview of the cut parts is on the pattern sheet). **Important:** Instructions do not include seam allowances, unless otherwise indicated.

SUPPLIES

- 1.5 – 1.6 m twill "23018", 145 cm wide (Hofstetter)
- Iron-on stabiliser H 180 (Vlieseline)
- Optional accessories
- Filmoplast H 54 (Vlieseline)
- Embroidery motifs "01, 03 and 24" from embroidery card "82001 Sepia Petals" via embroideryonline.com
- Embroidery Jumbo Hoop
- BERNINA embroidery machine
- BERNINA overlocker

CUTTING

1	1 × front part on the fold (after embroidering)
1	1 × front facing on the fold
1	4 × pocket bag
2	1 × back part on the fold
2	1 × rear facing on the fold
3	2 × sleeve

INSTRUCTIONS

1. Iron the Vlieseline on the facings and let them cool thoroughly. Divide the fabric for embroidering and mark the outlines of the whole upper front part on the fabric. Hoop the Filmoplast in the hoop and fix it with the function "Baste the outline of the motif". Align the embroidery files as desired around and beneath the neckline and embroider the front part. Remove the stabiliser. Make amendments to the outlines of the front part, if necessary, and cut it.
2. Close the darts in the front part. Close the shoulder seams of the dress and the facings.
3. Close the side seams up to the upper marking of the pocket mouth, secure the stitches, continue sewing the length of the pocket mouth with maximal stitch length, secure the stitches, shorten the stitch length and close the remaining side seam. Sew one pocket bag each right side on right side closely outside the seam line on the seam allowance of the front and back parts, making sure not to sew the allowances at the top and at the bottom. Iron the allowances apart. Clip the allowances of the front part above and beneath the pocket mouth down to the seam. Iron both pocket bags into the front part and sew them together. Undo the stitches along the pocket mouth. To reinforce the pocket mouth on the front part, sew a bartack at the top and at the bottom diagonally from the side seam through all fabric layers.
4. Sew the facing right side on right side along the edge of the neckline and clip the curves. Fold the facing inwards and fix it at the shoulder seams.
5. Hem the lower edge of the sleeves with the overlocker and a 3-thread rolled hem. Close the sleeve seams. Slightly gather the top shaping and sew the sleeves in. Hem the dress.